

TERRAIN AND BASE MAP INSTALLATION INSTRUCTIONS

Our previous map file update was missing the obstacle data. Please upgrade the map files as shown below. If you have any questions feel free to call us at 503-263-0037 x 1.

1. Start with the power off, and be sure to remove any existing SD Cards or USB drives
2. We highly recommend installing a [USB Extension Cable](#) for safe and easy drive access
3. Boot display(s) normally
4. Press I AGREE
5. Install one USB drive into the extension cable or one of the USB slots located on the back of each display
6. Press SET then hold CAL to enter Instrument Calibration
7. Press SEL for Admin Settings
8. Press SEL for Transfer Files

Configure Admin Setting		Transfer Files	
1. Upgrade Maps	No Maps Found	21. Very Low Res Terrain File	NEEDS UPDATE
2. Backup System Files To	SD	22. Low Res Terrain File	NEEDS UPDATE
3. Restore User Files From	SD	23. Base Map File	NEEDS UPDATE

9. Navigate with the Joystick to Upgrade Maps and press STRT
10. Press BACK, BACK, BACK to return to the main screens
11. Repeat steps on each AF-5000 Series display in the panel.

The USB Media must remain connected to each screen for proper operation.